

# Hinge Hugger Installation Instructions

## Driver's Side

1. Disconnect the door wire harness.
2. Unhook the door limit strap.
3. Remove the driver's side door and set it aside.
4. With the door removed, slide the driver's side Hinge Hugger (logo at bottom) straight down over the exposed Jeep door hinges until fully seated.
5. Reinstall the driver's side door, using the Hinge Hugger as a backstop while aligning the hinges.
6. Reattach the door limit strap.
7. Reconnect the door wire harness.

## Passenger's Side

1. Repeat steps 1-7 for the passenger's side door.

## Final Check

- Open and close both doors fully
- Confirm proper hinge alignment
- Verify wiring and limit straps are securely connected



\*Confirmed to fit 2007-2023 Jeep JK & JL Series Wranglers and Gladiators.

\*Hinge Huggers are not guaranteed to be automatic car wash safe.